

Eutech ORPTestr® 10 pocket size meter offers signature user-friendly features
Redesigned display features large LCD display, anti-roll housing, extended measurement range and more!

19 May, 2004

New user-friendly features packed in

Eutech Instruments introduces the redesigned [Eutech ORPTestr 10](#) pocket-sized meter that packs in more user-friendly features like the bigger 27mm (H) x 21mm (W) LCD screen, a redesigned IP67-rated housing that minimizes rolling, and a three-segment battery indicator for instant signal of battery life. The ORPTestr's user-replaceable double-junction sensor comes with wide platinum band for stable, quick response and makes it ideal for various on-site measurements even in rugged, wet environments.

Reliable features maintained

The ORPTestr 10 retains the existing features users have grown to rely on, including a Valox® electrode housing that resists most chemicals while protecting the glass electrode against breakage. The unit also uses replaceable electrode sensor that combine easy maintenance, and a double-junction construction that minimizes reference element poisoning. All these contribute to essential cost savings for the user. Plus, the waterproof floatable housing design allows you to attach a lanyard for easy retrieval.

ORPTestr delivers accuracy for a wide range of applications

With an extended measurement range from -999 to +1000 mV, the ORPTestr 10 offers ± 2 mV accuracy and offset adjustment up to ± 150 mV. These features make the ORPTestr ideal for industrial applications such as chromate reduction, cyanide oxidation and pulp bleaching as well as water treatment processes such as the monitoring of ozone systems, free chlorine activity (in pools, spas, and cooling waters), water purification and drinking water, aquarium monitoring and water pollution monitoring.

All meters are backed with a two-year warranty.

About Eutech Instruments

Eutech Instruments, a leading ISO 9001 certified water analysis instrumentation manufacturer and markets its comprehensive product range world-wide through an extensive distributor network. For more information, please contact our distributors or visit our corporate website at www.eutechinst.com

Press Contact Information:

Lee Hiang Koon

Email: hklee@eutechinst.com or marketing@eutechinst.com

Tel: +65-6778 6876 ext. 852

Fax: +65-6773 0836